



The First Name In Trailers














# Utility Trailer Sales of Georgia

P.O. Box 8

Ellenwood, GA 30294

Ph: (404)363-4387 Fax: (404)363-7361

## Interior Cargo Control

<h3>Logistic Straps</h3> <p>2" Webbing for use with E or A track</p>		 <h3>Rope Tie Down 660001</h3> <p>2" strap w/ E fitting.</p>
 <p>2"x20' - 652001 2"x16' - 651601 2"x12' - 651201</p>	 <p>2"x20' - 642001 2"x16' - 641601 2"x12' - 641201</p>	
<h3>Aluminum or Steel Decking Beams</h3>  <p>96" Aluminum adjusts 85" to 94.7" - FE8066-1 102" Aluminum adjusts 92" to 103" - FE8066-3 102" Steel adjusts 91.75" to 103" - FE1866</p>		<h3>E Track</h3>  <p>Horizontal</p> <p>Steel - 43002 Galvanized - 43001</p> <p>Vertical</p> <p>2019</p> <p>A Track also available</p>
<h3>Load Bars w/ Jack &amp; Hoop</h3>  <p>JB109 adjust 86" to 104" JB109XL adjust 86" to 114"</p>		<h3>"F" Track 2005</h3> <p>Horizontal or Vertical</p> 
<h3>Load Bar</h3> <p>Steel #10085 Aluminum #10088</p> <p>Available in aluminum or galvanized steel tubing. Easy one handle release Adjusts 89" to 105"</p> 		<h3>F Beam 1816-2</h3> <p>adjusts 92" - 106"</p> 
<h3>Load Bars w/ Jack</h3> <p>JB101 adjust 86" to 104" JB101XL adjust 86" to 114"</p> <p>Square jack bars are constructed of heavy wall steel for increased strength and durability.</p> 		<h3>Furniture Pads</h3> <p>72" x 80"</p> 
<h3>Series E Fitting w/ 1" Ring</h3> <p>FE8264-1</p> 	<h3>D Rings</h3> <p>45545-15</p> 	<h3>BarTender 10062</h3> <p>The BarTender is designed to provide storage for various types of load bars on the exterior of the tractor cab. The BarTender can be locked with a padlock to deter theft.</p> 